

FIG. 3








FIG. 4

FIG. 5



PISTON NORMALLY CLOSES
 INTAKE PORT

2ND SPRING NOT SHOWN









FIG. 11







FIG. 14




FIG. 15




FIG. 16




FIG. 17

